



**SMS Sanayi Malzemeleri ve Satısı A.S.**

## **REA 60 Electric Actuator Manual**



## **CONTENT**

### **INTRODUCTION**

### **PRODUCT IDENTIFICATION**

### **GENERAL INFORMATION AND FEATURES**

### **INSTALLATION INSTRUCTION**

### **ACTUATOR MOUNTING DETAILS**

### **OPERATION INSTRUCTION**

### **MAINTENANCE**

### **TROUBLE SHOOTING**

### **DIMENSION FOR ACTUATOR**

## INTRODUCTION

This installation and operating manual explains how to install, operate and maintain REA60 electric actuators. Safety notices in this manual detail precautions the user must take to reduce the risk of personal injury and damage to the equipment. User must read these instructions before installation, operating, or maintenance.



**DANGER:** Refers to personal safety. Alerts the user to potential danger or harm. The hazard or unsafe practice will result in severe injury or death.



**WARNING:** Refers to personal safety. Alerts the user to potential danger. Failure to follow warning notices could result in personal injury or death.

**CAUTION:** Directs the user's attention to general precautions that, if not followed could result in personal injury and/or equipment damage.

## PRODUCT IDENTIFICATION

The actuator name plate is located on the top cover of the actuator.

The name plate contains the following:

- TORK logo (trade mark)
- Electrical power supply
- Model
- Type
- Rated current
- Operating time (seconds)
- Serial No.
- Option

### SMS Sanayi Malzemeleri Uretim ve Satisi A.S.

## Initial Inspection

Upon receipt of the actuator, inspect the condition of the product and ensure the name plate matches the order sheet or your requirements, also check for any damage that may have occurred during shipment. If the wrong product has been shipped immediately or is damaged report to the coordinator.

## Storage

Actuators must be stored in a clean, cool and dry area. The unit shall be stored with the cover fastened and the conduit openings sealed. Storage must be off the floor, covered with a seal dust protector.

When actuators are stored outdoors, they must be stored off the ground, high enough to prevent being immersed in water or buried in snow.

## GENERAL INFORMATION AND FEATURES

REA series electric actuators are designed to provide reliable and efficient operation of 90 degree quarter turn valves , dampers, etc.

## Performance

MODEL	Maximum Output Torque Nm	Opreating Time(s) 50/60Hz	Duty Cycle S4(%)	Nominal Current(A) 60/50Hz				Weight Kg	Manuel Handwheel Turn N	Mounting Size ISO5210	
				AC		DC					
				110V	Capacitor(uF)	220V	Capacitor(uF)	24V			
REA-60	60	12/14	50%	0,39/0,4	5	0,2/0,19	1,2	0,4	3	8	F03,F04,F05

## SMS Sanayi Malzemeleri Uretim ve Satisi A.S.

Head Office : Bostancı Yolu Cad. Kuru Sok. No:16 Y. Dudullu, 34776 Ümraniye / İstanbul - Turkey  
Tel: +90 (216) 364 34 05 (pbx) Fax: +90 (216) 364 37 57

Factory: Çerkeşli OSB Mah. Dilovası İMES OSB 5.Cad. No:6 - Kocaeli / Turkey  
Tel: +90 (262) 290 20 20 Fax: +90 (262) 290 20 21

**Technical Data**

<b>Enclosure Rated</b>	Weatherproof IP67
<b>Enclosure</b>	High grade aluminium alloy, corrosion coated
<b>Power Supply</b>	110/220 VAC 1 Ph, 24 VAC - 24VDC 50/60Hz
<b>Motor</b>	Reversible motor
<b>Limit Switches</b>	2 x open/close SPDT, 250 VAC 10A rating
<b>Auxiliary Limit Switches</b>	2 x open/close SPDT, 250 VAC 10A rating
<b>Indicator</b>	Continuous position indicator
<b>Manual</b>	Manual Override Nut
<b>Space Heater</b>	2W
<b>Conduit Entries</b>	2 x PG 13.5
<b>Lubrication</b>	Grease moly EP
<b>Ambient Temperature</b>	-20°C~ + 70°C
<b>External Coating</b>	Dry powder polyester

**REA Option Technical Data**

PIU Potentiometer unit (0~ 1K Ω)

PCU Proportional control unit (input, output 0-10 VDC or 4-20mA DC)

CPT Current position transmitter (output 4- 20mA DC)

**Duty Cycle**

Duty cycle is rated IEC60034 - S4 50% / S2 30 min

Exceeding the actuators rated duty cycle may cause thermal overload.

Type of duty according to VDE 0530 / IEC 60034-1

**SMS Sanayi Malzemeleri Uretim ve Satisi A.S.**

### **Short - time duty S2**

The operation time at a constant load is short, so that thermal equilibrium is not reached. The pause is long enough for the machine to cool down to ambient temperature. The duration of the short - time operation is limited to 15 min (10 min, 30 min).

### **Intermittent duty S4**

The duty is a sequence of identical cycles which consist of starting time, operation time with constant load and rest period. The rest period allows the machine to cool down so that so that thermal equilibrium is not reached. The relative on-time at S4-25% or S4-50% is limited to 25% and 50% respectively .

### **Heater**

Condensation in the actuator is possible due to wide fluctuation of the ambient temperature. The heater integrated in the control unit prevents this in general.

### **Manual Hand Wheel and Lever**

REA actuators are provided with a manual operation system.

The REA60 actuator comes standard with a manual override nut.


This is located on the bottom of the unit, and can be easily operated with a 5M wrench.

Turn the hand wheel until the valve reaches the required position.

Turn clockwise to open and counter clockwise to close.



When nut becomes tight **DO NOT FORCE** further as this will cause serious damage to the gearing.




**Note:** The override engagement lever returns automatically to auto position when the actuator is operated electrically.

### Lubrication

REA is a totally enclosed unit with a permanently lubricated gear train (Moly EP Grease). Once installed lubrication should not be required. However, periodic preventative maintenance will extend the operating life of the actuator.

## External Parts




1. Top Cover
2. Body
3. Cable Entry(PG 13.5)x2
4. Drive Shaft
5. Mounting Base (F03, F05, F07)
6. Manual Override Nut
7. Name Plate
8. Cover Bolt (Captive Design)
9. Indicator

### **SMS Sanayi Malzemeleri Uretim ve Satisi A.S.**

Head Office : Bostancı Yolu Cad. Kuru Sok. No:16 Y. Dudullu, 34776 Ümraniye / İstanbul - Turkey  
Tel: +90 (216) 364 34 05 (pbx) Fax: +90 (216) 364 37 57

Factory: Çerkeşli OSB Mah. Dilovası İMES OSB 5.Cad. No:6 - Kocaeli / Turkey  
Tel: +90 (262) 290 20 20 Fax: +90 (262) 290 20 21

Internal Parts



1. Motor
2. Indicator
3. Open limit switch
4. Additional open limit switch
5. Potentiometer Unit
6. Terminal
7. Heater
8. Capacitor

## INSTALLATION INSTRUCTION

### Pre-Installation (for use in General Services)

Verify the actuators name plate to ensure correct model number, force, operating speed, voltage and enclosure type before installation and use.

It is important to verify that the output force of the actuator is appropriate for the force requirements of the valve and that the actuator duty cycle is appropriate for the intended application.



**WARNING:** Read this installation and maintenance manual carefully and completely before attempting to install, operate or trouble shoot the REA actuators.

### Actuator Mounting

#### Note:

- Prior to mounting the part-turn actuator it must be checked for damage.
- Damaged parts must be replaced by original spare parts.

Mounting is most effectively carried out with the valve shafting pointing vertically upwards, however mounting is also possible in any other position.


The REA series actuators are supplied with a Union Joint and nut which is removable for ease of machining.




#### CAUTION:

- Do not attempt to work on your REA actuator without first shutting off Incoming power.
- Do not attach ropes or hooks to the hand wheel for the purpose of lifting by hoist.



**ACTUATOR MOUNTING DETAILS**



\*Direct mounting / ISO (ISO standard)




\*Bracket Mounting



Star Adapter 14mm - 11 mm  
11mm - 9mm



Square Adapter 14mm - 11 mm  
11mm - 9mm




**Danger: HAZARDOUS VOLTAGE** (Make sure all power is disconnected prior to mounting)

## Limit Switch Setting

- Rotate the actuator hand wheel manually to closed position
- Using hex wrench, loosen the set screw on the CLOSE limit switch cam
- Rotate the CLOSE cam towards CW limit switch lever until the switch “clicks” Tighten the set screw with hex wrench
- Rotate the actuator hand wheel manually to open position
- Using hex wrench, loosen the set screw in the “open” limit switch cam
- Rotate to “open” cam towards CCW limit switch lever until the switch “clicks” (fig 2)
- Tighten set screw with hex wrench



**Danger: HAZARDOUS VOLTAGE** (Make sure all power is disconnected prior to mounting)




## Position Feedback Potentiometer (Optional)

### Calibration Potentiometer

The potentiometer has been calibrated at the factory, however if re-calibration is required proceed as follows:

- Apply power (or use manual override) to drive the actuator to its true closed position (clockwise rotation)
- Connect an ohmmeter to P1 (red) and P3 (black) resistance should be approximately 1000ohms
- Loosen the point shaft gear and connect the ohmmeter to P1 (red) and P2 (white) and gently rotate until a reading of 80 - 120  $\Omega$  is achieved (100 ohms preferred). While maintaining this reading tighten the point gear set screw with a hex wrench.



### Proportional Control Unit - PCU (Optional/REA Series)

#### Check point before using actuator

1. Check specification (Model No., Main Power, Control Power, Options) of delivered actuator meets your requirements.
2. Check application such as valve, damper etc.
3. Check mounting of actuator on application is correct.
4. Check setting of actuator such as limit switch, stopper bolts, indicator, is correct.
5. Check electrical wiring is correct.

6. In case of 3 phase motor, check

rotating direction. \*Check rotating direction of actuator, "open" actuator about 50% by manual, supply power to actuator for 2-3 seconds. Push close button and check if actuator moves to "close" direction. If this actuator moves to "close" it is correct. **To reverse the motor stop the power supply to the actuator and change the 2 of the 3 power lines which changes the direction of the motor.**

7. Generally all functions of PCU is set by the factory before delivery and there is no need to set the functions again. The functions should only be changed if the customer wishes to adjust the limit switches, to set the function the PCU is required. To set simply push the "Auto Setting" button after putting actuator in the 50% open (or close) position. PCU automatically sets all the functions by itself.

8. Disassembly modification without factory consent may affect the performance of the actuator.

### SMS Sanayi Malzemeleri Uretim ve Satisi A.S.

Before installing or operating the actuator, please read this manual to learn how to install and operate. The contents of this manual are subject to change due to quality improvement without individual notice.

## General Performance

PCU is the local actuator controller, using 12 bit A/D converter and 8 bits Microprocessor which operate the actuator to open and close according to the signal from the main controller. After operating actuator it detects the current position of the actuator and transmits a feedback output signal advising of the current position to the main controller .

## Standard Specification

- Model: PCU REV 3.1
- Model: 85V- 280 VAC  $\pm$  10% 50/60Hz 4VA Max (New wide range of voltage)
- Input Signal: 4-20mA DC, 2- 10VDC, 0- 5VDC, 0- 10VDC, 1- 5VDC **Input resistance: 250 Ohm**
- Feedback Signal: 100- 10 Kohm **Extraction: 2.3 VDC**
- Output Signal: 4-20mA DC, 2~ 10VDC, 0- 5VDC, 0- 10VDC, 1- 5VDC
- Load Resistance: 750ohm Max.
- Control Output: Relay contact 250VAC 10A Max (Inductive load)
- Number of Output Contact: 2 ea (Open and Close contact)
- Delay Time Adjustment: 0- 7.5 sec (1 Step 0.5 sec 0 - 15 Step)
- Dead Band Adjustment: 0.1- 4.5%
- Resolution: Min 1/1000
- Position Conversation Accuracy:  $\pm$ 1.5% (Depends on installation)
- Ambient Temperature: -10°C- +70°C
- Ambient Humidity: 90% RH Max (Non-condensate)
- Dielectric Strength: 1500V AC 1 Min (Input to Output, Power to Ground)
- Insulation Resistance: Min 500VDC 30Mohm
- Vibration & Shock (X, Y, Z): 6g based on RMF, Frequency: 0.2- 34Hz, 30 min

## SMS Sanayi Malzemeleri Uretim ve Satisi A.S.

Head Office : Bostancı Yolu Cad. Kuru Sok. No:16 Y. Dudullu, 34776 Ümraniye / İstanbul - Turkey  
Tel: +90 (216) 364 34 05 (pbx) Fax: +90 (216) 364 37 57

Factory: Çerkeşli OSB Mah. Dilovası İMES OSB 5.Cad. No:6 - Kocaeli / Turkey  
Tel: +90 (262) 290 20 20 Fax: +90 (262) 290 20 21

## LED Signal

LED Signal

Blue on Power on (Auto)


Blue Flicker Auto Setting

Green on Close

Red on Open

Yellow on Manual OPN.by card


Yellow Flicker Fault in either wrong input wiring,  
wrong PIU setting No input signal



## Check Operation of PCU

Actuator	Full Close	Full Open
Input Signal	4mA DC (1 VDC, 2VDC)	20mA DC (5VDC, 10VDC)
Output Signal	4mA DC	20mA DC
Signal LED	Green LED on	Red LED on
Auto Setting	Blue LED Flicker	
Input Signal Failure	Yellow LED Flicker	

Lay Out of PCU Card




## OPERATION INSTRUCTION


### Electrical Connections and Preliminary Test

- Loosen the screws on the actuator cover and lift it off
- Make sure that the power supply voltage is in accordance with the data on the actuator name plate
- Connect wires according to the enclosed wiring diagram
- Move the valve manually to a half-open position, operate and electrical opening and check that the motor rotates in the right direction
- Standard units are counter-clockwise to open set
- Test the actuator and check the limit switches work correctly
- Check all the cable glands are correctly tightened, applicable cable glands should be selected to be meet the applications condition. Over the grade IP67 of cable gland recommended in potentially explosive atmospheres.
- Mount cover and tighten cover bolts


### Wiring Diagram for 230V AC On/Off Type




**Wiring Diagram for 230V AC PCU Type**



**Wiring Diagram for 24VAC On/Off Type**




**Wiring Diagram for 24V DC On/Off Type**




DIP Switch setting

Suggested Customer  
Wiring



Actuator's  
Interior Wiring

AC OPERATION DIP SWITCH 1 DOWN - DIP SWITCH 2 UP



DC OPERATION DIP SWITCH 1 UP - DIP SWITCH 2 DOWN



## MAINTENANCE



**Caution:** Turn off all power services before attempting to perform a service on the actuator.

**POTENTIAL HIGH PRESSURE VESSEL.** Before removing or disassembling the actuator ensure the valve or other actuated devices are isolated and not under pressure.

Maintenance under normal conditions at six month intervals, however when conditions are more severe, more frequent inspections may be advisable.

- Ensure valve actuator alignment
- Ensure wiring is insulated, connected and terminated properly
- Ensure all screws are present and tight
- Ensure cleanliness of internal electrical devices
- Ensure conduit connections are installed properly and are dry
- Check internal devices for condensation
- Check power to internal heater
- Check enclosure O-ring seals and verify the O-ring is not pinched between flange
- Verify declutch mechanism
- Visually inspect during open /close cycle
- Inspect identification labels for wear and replace if necessary

## SMS Sanayi Malzemeleri Uretim ve Satisi A.S.

Head Office : Bostancı Yolu Cad. Kuru Sok. No:16 Y. Dudullu, 34776 Ümraniye / İstanbul - Turkey  
Tel: +90 (216) 364 34 05 (pbx) Fax: +90 (216) 364 37 57

Factory: Çerkeşli OSB Mah. Dilovası İMES OSB 5.Cad. No:6 - Kocaeli / Turkey  
Tel: +90 (262) 290 20 20 Fax: +90 (262) 290 20 21



**Warning:** Treat cover with care. Gap surfaces must not be damaged or dirtied in any way. Do not jam cover during fitting.

## Tools

- 1 Metric Allen Key (Hex Wrench)
- 1 Screw Driver
- 1 Metric Spanner
- 1 Wrench 200mm
- 1 Wrench 300mm
- 1 Wire Stripper Long Nose
- 1 Multi Meter (AC, DC, Resistance)
- 1 DC Signal Generator (4~20mA): PCU Board Option
- 1mA Meter (0-25mA): PCU Board Option

## TROUBLE SHOOTING

The following instructions are offered for the most common difficulties encountered during installation and start up.

SYMPTOM	PROBABLE CAUSE	CORRECTIVE ACTION
Motor not running	Open in control unit	Refer to appropriate wiring diagram and check for continuity
	Insulation resistance breakdown in motor	Perform megger test
No power available to actuator	Tripped circuit breaker	Reset circuit breaker
Manual override nut hard to turn	Valve stem improperly lubricated. Actuator lubricant has broken down	Lubricate with grease Clean out old grease and replace with recommended lubricant
	Valve packing gland too tight	Loosen gland nuts as necessary
	Jammed valve	Refer to valve maintenance
Valve only opens or closes partially with motor	Limit switch improperly set	Check setting and reset if necessary
Manual override nut will not operate valve	Stripped gearing	Replace as necessary
	Broken hand wheel shaft	Replace as necessary
	Broken valve stem	Repair or replace as necessary
Motor runs but will not operate valve	Stripped gearing	Replace as necessary

## SMS Sanayi Malzemeleri Uretim ve Satisi A.S.

Head Office : Bostancı Yolu Cad. Kuru Sok. No:16 Y. Dudullu, 34776 Ümraniye / İstanbul - Turkey  
Tel: +90 (216) 364 34 05 (pbx) Fax: +90 (216) 364 37 57

Factory: Çerkeşli OSB Mah. Dilovası İMES OSB 5.Cad. No:6 - Kocaeli / Turkey  
Tel: +90 (262) 290 20 20 Fax: +90 (262) 290 20 21

### **Actuator does not respond**

- Verify the line voltage to the actuator
- Check that the voltage matches the rating on the actuator nameplate
- Check internal wiring against actuator wiring diagram
- Check limit switch cams

### **Actuator is receiving power but does not operate**

- Verify the line voltage to the actuator
- Check actuator force to see if it's greater than the valve force
- Check limit switches and cams
- Check that the force switches have not tripped
- Check mechanical travel stop adjustment
- Verify the actuator against valve rotation (standard units are anti-clockwise open)
- Check internal wiring
- Check for corrosion and condensation
- Verify coupler/bracket are correctly installed and is not causing binding

### **Actuator runs erratically**

- Check ambient temperature
- Verify that the duty cycle has not been exceeded
- Check the position of manual override lever

### **Optional Equipment**





#### **Potentiometer Current Position Transmitter**

- Check resistance value
- Check potentiometer gear for jamming
- Check zero and span calibration
- Check board for damage

**DIMENSION FOR ACTUATOR**

**On/Off Type**

Enclosure: IP67  
Torque: 6Kg.m  
Operation Time: 13sec  
Position Switch: 4 SPDT Switch  
Cable Entry: PG 13.5 x 2  
Mounting Flange: F03, F05, F07  
acc to DIN/ISO5211




**SMS Sanayi Malzemeleri Uretim ve Satisi A.S.**

Head Office : Bostancı Yolu Cad. Kuru Sok. No:16 Y. Dudullu, 34776 Ümraniye / İstanbul - Turkey  
Tel: +90 (216) 364 34 05 (pbx) Fax: +90 (216) 364 37 57

Factory: Çerkeşli OSB Mah. Dilovası İMES OSB 5.Cad. No:6 - Kocaeli / Turkey  
Tel: +90 (262) 290 20 20 Fax: +90 (262) 290 20 21

**PCU Type**



**SMS Sanayi Malzemeleri Üretim ve Satış A.Ş.**

Head Office : Bostancı Yolu Cad. Kuru Sok. No:16 Y. Dudullu, 34776 Ümraniye / İstanbul - Turkey  
Tel: +90 (216) 364 34 05 (pbx) Fax: +90 (216) 364 37 57

Factory: Çerkeşli OSB Mah. Dilovası İMES OSB 5.Cad. No:6 - Kocaeli / Turkey  
Tel: +90 (262) 290 20 20 Fax: +90 (262) 290 20 21